

FLEX-Elektrowerkzeuge GmbH
Bahnhofstraße 15
71711 Steinheim
Phone +49 7144 828-0
Fax +49 7144 25899
info@flex-tools.com
www.flex-tools.com

2-speed cordless mixer with 3-level speed switch 18.0 V

MXE 18.0-EC WR2 120

Order number 495.964



2-speed cordless mixer with 3-level speed switch 18.0 V

- + Electronic management system (EMS) protects the machine, extends the service life, and increases efficiency
- + Brushless motor with greater efficiency and a longer service life
- + Large, rugged 2-gear unit with optimum ratios for powerful torque and correct speed for different materials
- + Comfortable 3-level switch can be reached from the grip position without interrupting work, protected by a rubber sleeve. Level 1: cleaning, level 2: stirring up, level 3: mixing
- + Rotary switch to set the optimum mixing speed. Speed 1: for highly viscous materials, speed 2: for medium and low viscosity materials
- + Accelerator switch for a slow and gentle start
- + On/off switch with lock and protection
- + The flexible rubber sleeve over the on/off switch prevents the ingress of dirt. No malfunctions caused by jammed switches
- + Ergonomic handles on the drive unit: low weight, fatigue-free arm posture and upright body posture allow comfortable, ergonomic operation
- + Four corner guards with rubber buffer provide secure storage during transportation and offer protection against shocks and impacts at the building site
- + Protective cap above the motor housing guides the cooling air flow and prevents the ingress of splashing water
- + Patented spindle lock with start-up protection. For tool-less exchange of the mixing paddle
- + For mixed applications up to 30 kg
- + With mixing paddle WR2 for mixture: pasty to tough. Tile adhesive, grout, filler compound, adhesive, finished plaster, adhesive mortar, ...
- + FLEX battery system: suitable for all FLEX 18,0 V battery packs. Delivery does not include battery and charger